



SAFETY **FIRST**

PLEASE POST THESE SAFETY RULES NEAR MACHINE FOR REFERENCE

SAFETY RULES for **DEWALT**

MOTORIZED MITER BOX

1. **WEAR** eye protection.
2. **DO NOT** operate saw without guards in place.
3. **DON'T** use the tool in the presence of flammable liquids or gases.
4. **CHECK** the blade carefully for cracks or damage before operation. Replace cracked or damaged blade immediately.
5. **USE ONLY** flanges specified for this tool.
6. **BE CAREFUL** not to damage the arbor, flanges (especially the installing surface) or bolt. Damage to these parts could result in blade breakage.
7. **MAKE SURE** that the turn base is properly secured so it will not move during operation.
8. **REMOVE** chips, small pieces, etc. from the table top before operation.
9. **DO NOT CUT USED LUMBER.** Inspect lumber for any nail, staples, and metal objects.
10. **MAKE SURE** the shaft lock is released before the switch is turned on.
11. **BE HELPFUL** that the blade does not contact the turn base in the lowest position.
12. **HOLD** the handle firmly. Be aware that the saw moves up or down slightly during start-up and stopping.
13. **DO NOT** perform any operation freehand. The workpiece must be secured firmly against the turn base and guide fence during all operations.
14. **KEEP** hands out of path of saw blade. Avoid contact with any coasting blade. It can still cause severe injury.
15. **NEVER** reach around saw blade.
16. **MAKE** sure the blade is not contacting the workpiece before the switch is turned on.
17. **BEFORE** using the tool on an actual workpiece, let it run for a while. Watch for vibration or wobbling that could indicate poor installation or a poorly balanced blade.
18. **WAIT** until the blade attains full speed before cutting.
19. **STOP** operation immediately if you notice anything abnormal.
20. **DO NOT** attempt to lock the trigger in the on position.